









XS4 One S SKG** models



The XS4 One S product line is a universally compatible advanced smart locking system delivering next-generation access control technology in a market-proven solution. Unique, simple to install and retrofit, and featuring a sleek design, the XS4 One S platform integrates all your physical security needs through wireless networked, stand-alone locks giving you real-time access control for virtually all the doors in your building.


E i 850xx.. series






(Eng) Select handing (E) Seleccione mano (D) Drückerrichtung wählen
 (F) Choisir le sens de la bêcheille (I) Scegliere il verso (P) Seleccione mão


1




2




3




4




5




6




7




1




2




3




4




5




6




7



8



9



(Eng)

**AT THIS POINT DO NOT
CLOSE THE DOOR
PROGRAM THE LOCK FIRST**

(E)

**NO CIERRE LA PUERTA.
PROGrame LA CERRADURA**

(D)

**TÜR NICHT SCHLIESSEN.
ZUERST SCHLOSS
PROGRAMMIEREN**

(F)

**NE FERMEZ PAS LA PORTE.
PROGRAMMEZ LA BÉQUILLE
AVANT**

(I)

**PROGRAMARE LA
SERRATURA
PRIMA DI CHIUDERE LA PORTA**

E i 850.. S series

